Weller®

Operating Instruction WX / WT Foot switch



Requirements:

WXD2 or WXA2 soldering station and WXR3 rework station:

Firmware version 065 or higher

WTHA1 hot air station **Networkconfiguration:**

WXD2 / WXA2 / WXR3 / WTHA1




Fußschalter Foot switch Contact Pédale Comando a pedale Pedal interruptor Interruptor de pé



T0058764710

WX solder station*







Foot switch (not pushed)



Foot switch (pushed)

*(Note: WX foot switch is only connectable to FRONT RS232 PORT)

Weller Tools GmbH

Carl-Benz-Str., 2 74354 Besigheim, Germany Phone: +49 (0) 7143 580-0 info@weller-tools.com

Apex Tool Group, LLC 1000 Lufkin Road Apex NC 27539 USA

Phone: +1 (800) 688-8949

The data specified above only serve to describe the product. No statements concerning a certain condition or suitability for a certain application can be derived from our information. The given information does not release the user from the obligation of own judgement and verification. It must be remembered that our products are subject to a natural process of wear and aging. © This document, as well as the data, specifications and other information set forth in it, are the exclusive property of WellerTools GmbH. Without their consent it may not be reproduced or given to third parties. Subject to modifications.

Printed in Germany. T005 57 365 00 / 09.2019

